Customizing Your Lexus

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

ltem	Function	Default setting	Customized setting
Smart access system with push-button start	Smart access system with push-button start	On	Off
	Operation signal (Emergency flashers)	On	Off
	Wireless remote control	On	Off
Wireless remote control	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	On	Off
	Time elapsed before automatic lock function is	60 seconds	30 seconds
	activated if door is not opened after being unlocked	oo seconds	120 seconds
	Operational signal (Emergency flashers)	On	Off
	Door lock buzzer	On	Off
	Trunk unlocking operation	Press and hold	Press twice One short press
	Panic function	On	Off

ltem	Function	Default setting	Customized setting
Door lock	Speed-detecting automatic door lock function	Off	On
	Opening driver's door unlocks all doors.	Off	On
	Shifting gears to "P" unlocks all doors.	On	Off
	Shifting gears to position other than "P" locks all doors.	On	Off
	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
Trunk	Power trunk opener and closer function	On	Off
Power windows	Mechanical key linked operation	On	Off
	Mechanical key linked operation	Open and close	Open only Close only
	Wireless remote control linked operation	On	Off
	Linked entry operation	On	Off
Moon roof	Mechanical key linked operation	On	Off
	Mechanical key linked operation	Open and close	Open only Close only
	Linked operation of components when door key is used	Slide only	Tilt only
	Wireless remote control linked operation	On	Off
	Linked operation of components when wireless remote control used	Slide only	Tilt only
	Linked entry function	On	Off

Customizing Your Lexus

ltem	Function	Default setting	Customized setting
	Light sensor sensitivity	Level 3	Levels 1 to 5
Automatic light	Time elapsed before headlights		0 seconds
control system	automatically turn off after	30 seconds	60 seconds
	doors are closed		90 seconds
Lights	Daytime running light system (U.S.A. only)	On	Off
	Buzzer volume	Level 3	Level 1 to 5
Intuitive parking	Distance at which the front and		
assist-sensor	back sensors detect an	Level 1	Level 2
	obstacle		
	Time elapsed before lights turn	15 seconds	7.5 seconds
Illumination	off	10 30001103	30 seconds
	Operation when the doors are unlocked	On	Off
	Operation after the "ENGINE		
	START STOP" switch is turned OFF	On	Off
	Footwell lighting	On	Off
	Shift lever lighting	On	Off
	Outer foot lights	On	Off
Seat belt	Vehicle speed linked seat belt	On	Off
reminder	reminder buzzer	OII	U

■ Multi-information display

Country	Available languages	
U.S.A.	English and Spanish	
Canada	English, French, German, Spanish and Italian	

Memo	

Memo



Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

■U.S. OWNERS

● In the U.S. mainland or Canada: Lexus Roadside Assistance

1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

●In Hawaii:

Servco Automotive Roadside Assistance/Customer Services

1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

■CANADIAN OWNERS

In Canada or the U.S. mainland:

Lexus Roadside Assistance/Customer Service 1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our websites for further information.

- The U.S. mainland: www.lexus.com
- Hawaii: www.servcolexus.com
- Canada: www.lexus.ca

©2007 TOYOTA MOTOR CORPORATION

All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.